VoIP 101

Welcome to your new Mitel 6867i phone.

The “67i” is the default VoIP (Voice over Internet Protocol) phone for IUP. It comes with 2 call appearances of your phone number (buttons L1 and L2), speakerphone, call transfer, forwarding, conferencing, voicemail, and many other capabilities. Please explore the buttons on your phone (as shown below) and see what will be useful for you.

1. **Placing a Call**
    a. Take the phone off-hook by either lifting the handset, pressing the L1 or L2 button, or by pressing the green **Speakerphone**

11. **Navigation**
    a. User interface navigation on the 67i can be performed by using the multi-directional navigation control located to the right of the

b. Enter the number of the party you wish to transfer the call to – the call will automatically dial.
    i. For a “blind” transfer, press the **Transfer** button again before the receiving party answers.
    ii. For a “consultative” transfer, remain on the line to speak with the called party to let them know that you are transferring a call to them, then press the **Transfer** button again.

14.Conference Calls

a. You can create a conference call with up to 15 participants on the

c. Using the down arrow navigation, move to the “On” checkbox beside the respective **Call Forward** mode(s) and press the select button to enable that mode.
d. Press the “Save” softkey to save your changes.

16.Do Not Disturb

a. Press the programmed **DND** softkey to turn on the **Do Not Disturb**

i. Press the **Directory** button and begin to enter either the first or last name of the person you would like to find.
    1. Spell out the name by pressing a number button one, two, three, or four times for each letter in the name.
    2. Use the softkey to put spaces in the name.
    3. Partial names can also be entered.

ii. Use the "Lookup" softkey or **Navigation** select key to start the search.

iii. When the search is complete, use the **Navigation** up or down arrows to select the person you are looking for.

iv. Use the "Dial" softkey to call the person you have selected.

19. Options

a. The **Options** button in the lower left set of buttons allows you to customize certain features on your phone such as ring tones and display settings. After pressing the **Options** button, use the **Navigation** up or down arrows to v0 Tmplete, use the

20.Voicemail

a. You can access **Voicemail** by pressing the **Voicemail** button in the lower right set of buttons on your phone or by dialing **724-357-1287** if you are away from your phone.

b. The first time you enter the **Voicemail** system you should enter the default passcode of **701798** when prompted. You will then be asked to change the passcode and to record your name. Your new passcode must be between 6 and 12 numeric characters and cannot include your extension/phone number.

c. It is recommended that you record Busy and No Answer Greetings immediately, as shown below in **Access Voice Messages**.

d. In the **Voicemail** system, choose from the following options:

    i. Access Voice Messages – press 1

        1. Press 1 to listen to messages

            a. Press # to save the message

            b. Press 7 to delete the message

            c. Press 2 to repeat the message

            d. Press 5 to hear the Message Envelope (information about the call date, time, and caller)

            e. Press 9 for additional options

                i. Press 1 to reply to the message

                ii. Press 2 to forward the message

        2. Press 2 to access the **Busy Greeting** menu

            a. Press 1 to record a new Busy Greeting

            b. Press 2 to listen to the current Busy Greeting

c. Press 3 to revert to the default Busy Greeting
d. Press # to repeat the options
e. Press * to return to the previous menu

3. Press 3 to access the **No Answer Greeting** menu
    a. Press 1 to record a ne

e. Press 7 to set or clear a Confidential Indicator
f. Press # to repeat the options
g. Press * to return to the previous menu

6. Press 7 to delete all messages
7. Press # to repeat the options
8. Press * to return to the previous menu

ii. Record Greetings – press 3

1. Press 1 to record your **Name**
    a. Press 1 to record your name
    b. Press 2 to play current recording
    c. Press # to repeat the options
    d. Press * to return to the previous menu
2. Press 2 to record a **Conference Greeting**
    a. Press 1 to activate the Conference Greeting
    b. Press 2 to deactivate the Conference Greeting
    c. Press 3 to record a new Conference Greeting
    d. Press 4 to listen to the current Conference Greeting
    e. Press # to repeat the options
    f. Press * to return to the previous menu
3. Press # to repeat the options
4. Press * to return to the previous menu

iii. Record Announcements – press 5

1. Press 1 to record an **Audio Announcement**
    a. Press 1 to accept the recording